


# SR 591

EN

## Spare parts / Accessories



<b>No.</b>	<b>Description</b>	<b>Ordering No.</b>
1.	Welding shield	H06-4312
2.	Head harness	R06-4303
3.	Sweatband, 5 pack	R06-4304
4.	Comfort band, neck	R06-4510
5.	Welding filter, shade No. 8, SR 59008	T06-4001
	Welding filter, shade No. 9, SR 59009	T06-4002
	Welding filter, shade No. 10, SR 59010	T06-4003
	Welding filter, shade No. 11, SR 59011	T06-4004
	Welding filter, shade No. 12, SR 59012	T06-4005
	Welding filter, shade No. 13, SR 59013	T06-4006
	Welding filter, EN 3/10, SR 59005	T06-4007
	Welding filter, EN 3/11, SR 59006	T06-4008
	Welding filter, EN 4/5-13	R06-4508
	Welding filter, 4/9-13, SR 59007	T06-4009
6.	Protective lens	R06-4008
7.	Inner protective lens for auto lens	R06-4009
	Inner protective lens for R06-4508	R06-4509
	Inner protective lens for toughened mineral glass lens	R06-4008
8.	Correction lens, dptr 1,0, SR 59014	T06-4010
	Correction lens, dptr 1,5, SR 59015	T06-4011
	Correction lens, dptr 2,0, SR 59016	T06-4012
	Correction lens, dptr 2,5, SR 59017	T06-4013
9.	Holder welding filter	R06-4306
10.	Screw	R06-4305
11.	Protective hood	T06-4014
12.	Cleaning tissues SR 5226, box of 50	H09-0401