


# SR 575

## Spare parts / Accessories



| No.. | Description   | Ordering No.         |
|------|---|----------------------|
| 1.   | Breathing hose  | R06-0635             |
| 2.   | Gasket for hose   | R01-3011             |
| 3.   | Exhalation membrane   | R06-0614             |
| 4.   | Head harness  | R06-0601             |
| 5.   | Head harness seal   | R06-0610             |
| 6.   | Sweatband   | R06-0602             |
| 7.   | Face seal<br>Face seal, flame retardant                               | R06-0603<br>T06-0611 |
| 8.   | Visor set, PC<br>Visor set, TAC                                       | R06-0616<br>T06-0612 |
| 9.   | Protective film, 10 pcs<br>Protective film, 100 pcs                   | T06-0601<br>T06-0608 |
| 10.  | Clips for protective film   | T06-0607             |
| 11.  | Chinstrap   | T06-0620             |
| 12.  | Neck cover<br>Neck cover, flame retardant                             | T06-0603<br>T06-0610 |
| 13.  | Cover with thread and knob  | T06-0640             |
| 13a  | Knob complete   | R06-0821             |
| 14.  | Visor 2/3 EN 5<br>Visor 2/3 EN 3<br><i>Note! T06-0640 is required</i> | T06-0605<br>T06-0609 |
| 15.  | Cleaning wipes, box of 50   | H09-0401             |
| 16.  | Hose protection, PE<br>Hose protection, SR 59021                      | T06-0121<br>T06-4016 |
| 17.  | Tyvek Hood SR 586   | T06-0806             |
| 18.  | Comfort kit   | T06-0606             |
| 19.  | Mic cable electret  | T09-0001             |
| 20.  | Welding shield SR 574   | T06-0613             |