


Spare parts / Accessories



No.	Description	Ordering No.
1.	Hood SR 601	R06-5401
2.	Hood SR 602	R06-5501
3.	Hood SR 604	R06-5901
4.	Head harness	R06-0601
5.	Air-duct	R06-5402
6.	Breathing hose	R06-0635
7.	Hose protection PE	T06-0121
8.	Gasket for hose	R01-3011
9.	Sweat band	R06-0602
10.	Protective film, 10 pcs	T06-0401
	Protective film, 100 pcs	T06-0402
11.	Comfort kit	T06-0606
12.	Cleaning wipes. Box of 50	H09-0401