

Operating instructions

Fit test adapter



1. Donning



1.1 The test adapter is used for connecting the SR 100/SR 900 half mask and SR 200 full face mask to a test instrument (via the black tube) for carrying out a face fit test.

Fit a particle filter SR 510 P3 R to the adapter.



1.2 Fit the adapter and particle filter in the mask.

Fit the measuring tube through the inhalation valve on the mask.



1.3 Cut the tube so it does not touch the test persons mouth/lips.



1.4 The adapter is intended for use only for face fit testing under test conditions. It must not be used under real work conditions.